




LORA DICARLO

OSÉ

USER GUIDE





THE PLEASURE IS ALL YOURS


For any additional information, please visit loradicarlo.com/faq, or contact us at hello@loradicarlo.com.

MATERIALS AND QUALITY

Osé is made from high quality, body-safe materials, including premium silicone and ABS plastic. Our products are phthalate and latex-free and are in accordance with international standards for materials, production, and safety. For more information, please see loradicarlo.com/faq.

QUICK START – GET TO KNOW OSÉ


- A G-spot Massager** – mimics the touch of a partner's finger to stroke the G-spot using a come-hither motion.
- B Flexible Body** – molds to your unique anatomy for a custom fit that reaches both pleasure points.
- C Clitoral Stimulator** – rests between the outer labia to provide thrumming throughout the full body of the clitoris.
- D Clitoral Mouth** – replicates the sensation of the mouth and tongue over the glans clitoridis using air technology.
- E Power Button** – turns Osé ON/OFF.
- F Control Panel** – controls the intensity of the Clitoral Stimulator and G-spot Massager, as well as the length of strokes over the G-spot.



QUICK START – OSÉ CONTROL PANEL

Each setting can be enabled and controlled individually, so you can truly customize each sensation.

- 1 Power Button** – press and hold for 2 seconds to turn Osé ON/OFF.
- 2 Clitoral Stimulator Button** – increase (+) or decrease (-) the intensity of clitoral stimulation with 10 intensity levels.
- 3 G-spot Speed Button** – increase (+) or decrease (-) the speed of G-spot Massager with 10 stroke speeds.
- 4 G-spot Stroke Button** – select short or long strokes over the G-spot.
- 5 Magnetic Charging Points** – magnetically connects to the USB charging cable provided.



CHARGING OSÉ

Charge Osé for at least 1 hour before the first use by placing the magnetic charging cable over the two metal dots on the back of the device and connecting to a safe power source with the provided USB charging cable.

Once plugged in Osé will display the charging status by gradually lighting the circle around the power button. When the circle is fully lit with a solid white light, your device is fully charged.

Note: Do not charge while in water or while the product is wet. Always make sure the USB charging cable and charging points on the device are completely dry before charging.



25% charged



50% charged



75% charged



100% charged

Use only the official Lora DiCarlo USB charging cable to ensure safe and effective charging.

CHECKING YOUR CHARGE

Each time you turn the product on the circle around the power button will light up to indicate the amount of charge remaining.

LOW POWER WARNING

The circle light will begin to pulse when there are 5 minutes of use time remaining.

AUTO-SHUTOFF

If the G-spot Massager or Clitoral Stimulator are not activated within 5 minutes, Osé will turn off automatically to conserve power.

UNDERSTANDING PLEASURE POINTS

THE CLITORIS

The clitoris is one of the most sensitive erogenous zones due to its high concentration of nerve endings. The glans clitoris is the outer portion you can see and sits at the top of the vulva, resting beneath the clitoral hood. The full body of the clitoris is larger than most assume, extending down around the vaginal entrance and deep into the front wall of the vaginal canal. Osé is designed to hug the clitoris and stimulate the full structure – both inside and out.

THE G-SPOT


It is theorized that the G-spot is actually the deeper portion of clitoral tissue. In most people the G-spot is about 1–3 inches (2–8cm) inside the entrance on the front wall of the vagina. The tissue tends to be slightly firmer and more rigid than the surrounding tissue. Osé is designed to press and stroke the full length of the G-spot.



FINDING YOUR PERFECT FIT

Before first time use, we recommend familiarizing yourself with your own anatomy to understand how Osé will adapt to fit comfortably against your pleasure points. It may take a few sessions to


explore and find the position and features you prefer. Note how the Clitoral Mouth should fit between the outer labia and over the glans clitoridis.



FINDING YOUR PERFECT FIT

The diagram below shows Osé in use against a body. Take note of this general position, including the bend of the Flexible Body that allows for a custom fit. Everyone's body is different so it may take some

exploration to find your personal fit – and it may look different from any of the examples in this manual. Take your time and enjoy the self-discovery!



USING OSÉ

USING THE G-SPOT MASSAGER

- We recommend testing out Osé's functions before inserting into the vagina so you can see all of the options and settings.
- **Only insert or remove Osé when it is fully turned off and the G-spot Massager is completely retracted.**
- Add a small amount of water-based lubricant or personal moisturizer to the G-spot Massager for smooth insertion and use.
- Gently insert the G-spot Massager into the vaginal opening with the Clitoral Stimulator facing up and towards the front of the body.
- Once inserted, turn Osé on and explore to find a position that presses against the G-spot. Adjust the angle of the massager to press securely and stroke over the inside front wall of the vaginal canal.

- Once the approximate location of the G-spot has been located, bend and adjust the Flexible Body to pinpoint the final position.
- Each of Osé's functions can be controlled independently, so try out different combinations of stimulation to find your favorite settings.

USING THE CLITORAL STIMULATOR

- Osé has two unique parts that provide stimulation to the clitoris: the Clitoral Mouth and Stimulator— see diagram on page 6.
- The Clitoral Mouth is designed to be placed over the glans clitoris (the part of the clitoris you can see) or against any part of the vulva.
- The Clitoral Stimulator is designed to rest against the vulva, pressed against the inner labia and in between the outer labia. This allows the unique

ridges of the stimulator to thrum against the parts of the clitoris hidden below the surface.

- Bend and adjust the Flexible Body to find the preferred position over the clitoris.

USING THE FLEXIBLE BODY

- The Flexible Body can be molded into a wide range of positions to fit your unique anatomy. We recommend bending and shaping it before use. The diagrams below show just a few of the possible positions.
- Bend the Flexible Body to find your position and control the level of contact against each pleasure point.

- Alternatively, bend the Flexible Body to position the Clitoral Stimulator or the G-spot Massager away from the body to use each function independently.
- You can increase or decrease the intensity and pressure of the G-spot stimulation by changing the angle of Osé or molding the Flexible Body. Bringing the G-spot Massager and the Clitoral Stimulator closer together increases the pressure and further apart creates a less intense sensation. The tighter the feel, the more likely it will stay in place.



Example 1



Example 2



Example 3



Example 4

USING OSÉ

PRODUCT LOCK

To ensure Osé doesn't turn on at the wrong time, such as during travel, you can disable and lock all of Osé's buttons. First hold the G-spot stroke button down, then press and hold the power button, the LED will flutter rapidly to signify lock. Repeat this combination to unlock the device and the LED will flutter again.

CLEANING, STORAGE, AND SAFETY

Always clean Osé with mild soap and water or a purpose-made, silicone-safe cleanser before and after each use. Osé is waterproof so you can run it under the faucet or fully submerge it for thorough cleaning. Be sure to clean inside the clitoral mouth as well using a finger, soft cloth, or cotton swab. Wipe dry with a clean lint-free cloth and store in a cool, dry location.

Use only water-based lubricants and personal moisturizers, as oil or silicone-based formulas can damage the materials and reduce the lifespan of your device.

Note: Do not boil, microwave, or run Osé through a dishwasher or sterilizer, as extreme heat and harsh detergents can damage the product. Do not use silicone, alcohol, acetone, petroleum, acidic, or alkaline-based products on Osé as it can damage the product materials.

WARNINGS

DISCLAIMER: Users of this Lora DiCarlo product do so at their own risk. Neither Lora DiCarlo nor its retailers assume any responsibility or liability for the use of this product.

Further Lora DiCarlo reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person. Model may be changed for any improvements without notice.

This product is intended for vaginal and clitoral use only.

This product is intended for adults only.

WARNING: Do not remove or insert your Osé until it is fully powered off. Removal or insertion before the device has fully retracted may result in discomfort, pain or injury or damage to the device. If you experience any pain or discomfort while using Osé, stop use and contact your medical provider.

OSÉ SPECIFICATIONS

Materials: Silicone and ABS plastic

Overall Product Size:

H 202mm x W 73.6mm x L 102.9mm

Insertable Length: 115mm

Insertable Width: 35mm

Clitoral Stimulator Size:

Outer cup dimension: 43 x 60mm

Inner cup dimension: 15 x 20mm

Weight: 268 grams

Battery: Rechargeable

Charging: 2 hours

Use Time: 1 hour

Interface: 4 Button

WARRANTY TERMS & CONDITIONS

Lora DiCarlo products are of the highest quality and come with a 1-year worldwide manufacturing warranty for products purchased from loradicarlo.com or an Authorized Retailer. Products purchased from an Unauthorized Retailer are not covered under these policies.

In countries mandating a longer warranty time, Lora DiCarlo extends the warranty accordingly.

REGISTERING YOUR PRODUCT

To claim your warranty you must register your product on loradicarlo.com and follow the instructions provided to make a warranty claim. If approved you will receive a Return Authorization Code (RAC) which should be included with the defective product when shipping to the provided return shipping address. Shipping costs are non-refundable. This undertaking is in addition to

consumer's statutory rights and does not affect those rights in any way.

Please contact hello@loradicarlo.com if you have any questions about your warranty eligibility or the registration process.

1-YEAR WARRANTY

Lora DiCarlo warrants this product for a period of one (1) year, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a qualifying defect and notify Lora DiCarlo during the warranty period, Lora DiCarlo will, at its discretion, repair or replace the product free of charge.

The warranty covers working parts that affect the function of the product. It does not cover cosmetic deterioration caused by fair wear and tear or damage caused by accident, misuse or neglect. Any

WARRANTY TERMS & CONDITIONS

attempt to open or take apart the product (or its accessories) will void the warranty.

Claims under warranty must be supported by reasonable evidence that the date of the claim is within the warranty period. To validate your warranty, please keep your original purchase receipt together with these warranty conditions for the duration of the warranty period. If you purchased your product on loradicarlo.com we already have your proof of purchase on file.

To activate your warranty, visit loradicarlo.com, log in, and register your device and follow the warranty claim process as indicated.

DISPOSAL

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.



COMPANY INFORMATION

Designed in Oregon, USA
by Lora DiCarlo.

Manufactured by Lora DiCarlo
in China.

Website: loradicarlo.com
Support: hello@loradicarlo.com



© 2019/2020 Uccellini, LLC. All rights reserved. US and international patents or patent applications apply to this product, visit loradicallo.com/IP for more information.